

Visit the Iowa Scaled Engineering website and store to learn more about our full line of model railroad electronics.

www.iascaled.com



Receiver for NCE Cab Bus and Lenz XpressNet



**IOWA SCALED ENGINEERING – ELECTRONICS MADE EASY!** 

**Power Status LEDs** 

Green (D1, 5V)

**Function** 


Green (D3, 3.3V) 3.3V power is on


5V power is on

**LED** 

### **Radio Module Status LEDs**

LED	Function
Red (D5, ASSOC)	(Blinking) Radio module is working
Vallow (D/L RSSI)	RE data is being received by the radio module





**Receiver Status LEDs** 

**Packet Status LEDs** 

LED

LED	Function
Red (D9, COLLISION)	(Blinking) Another
	receiver is using the
	same Base Address;
	(Solid) Another Cab
	Bus or XpressNet
	device is using the
	same Cab Number
Blue (D8, RESPONSE)	A command from a
	ProtoThrottle was
	successfully sent over
	Cab Bus or XpressNet
Blue (D7, XBEE RX)	A valid ProtoThrottle
	command was
	received by the
	radio module
Blue (D6, PING)	The command station
	is actively polling this
	receiver's Cab Number

Cab Bus

**Function** 

is active

Note: the throttle and receiver ship with a default base address of zero (0). Any address will work as long as both the throttle and receiver are configured to the same value. The only time to change it would be to avoid conflicts with other ProtoThrottle systems nearby.

# **Getting Started**

Step 1: Configure the DIP Switches

Step 2: Connect to the command station

**Step 3:** Configure the ProtoThrottle

Have Fun!

### www.protothrottle.com

# **DIP Switch SW2 Configuration Settings**

Switch	Function
A	ON = Lenz XpressNet
	OFF = Cab Bus
В	Unused
FT	ON = Broadcast NCE fast
	clock data
	OFF = Do not transmit fast
	clock data

Base Address: Set the radio base address of this receiver. Add the value(s) of the switches that are in the ON position to get the address. Program this value into the ProtoThrottle using the COMM CFG - BASE ADR menu. The base address should not be the same on any receivers within radio range of each other. Example shown above: 2 + 1 = 3If there is a base address conflict, the Collision LED (D9) will blink red.

## **DIP Switch SW1 Configuration Settings Function**

Switch

С	Unused			
D	Unused			
Cab Number:	Set the Cab Bus cab			
number, or X	oressNet address, of this			
receiver. Add the value(s) of the switches				
that are in the ON position to get the				
address. The cab number or address				
should not be the same as any other				
device connected to the command				
station.				
Example show	wn above: 4			

If there is a cab number or address conflict, the Collision LED (D9) will light solid red.